


TCM Connector, viewing open end of harness connector.

Pin numbers are from the board labelling that this connector mates to.



TCM Board, viewing into open connector. Pin numbers come from the labels on the board, and will possibly disagree with the FSM.

